

General Specifications

GS 11A00V01-01E-A

Model YARS100
Advanced Reflux Sampler



The Advanced Reflux Sampler is a self contained two stage system designed to provide simple, fast and highly accurate sample conditioning analysis for severe process applications.

Filtration of particulate and passive cooling are accomplished in the first stage of the sampler and as the sample reaches the second stage, it is directed through a transition piece which channels the gas evenly across two active cooling elements. These cooling elements provide 360° contact between sample and coolant. As the cooling takes place, condensate and Heavy Hydrocarbons are removed from the sample and gravity fed back through the reflux section, washing the sample inlet of particulate and other fouling compounds.

Temperature is tightly controlled with a single point temperature measurement fed to a controller which cycles the two active cooling elements resulting in higher analysis accuracy.

Features:

- Self Actuating or Electronic Version available
- Tight temperature Control for Higher Accuracy
- Larger Cooling Capacity Reduces Utility Costs
- Higher Sample Flow for Faster Analysis
- Reduced Maintenance – All Components Field Serviceable

Typical Applications:

- Ethylene Furnace Cracked Gas TLE
- Ethylene Furnace De-Coke Header



SPECIFICATIONS

Mounting	Vertical
Controller	Self Acting (Fixed or Adjustable) or Electronic (integral PID or plant DCS)
Wetted Material	316SS, Titanium, Hastelloy, Carpenter 20 (other materials available)
Inlet Connection	Flanged (typical 1", 2" OR 3" 150# OR 300# RF ANSI)
Sample Temperature	50°-1500° F
Inlet Pressure	2 - 600 PSIG
Sample Outlet Temperature	40° - 200° F
Sample Flow	1-5 LPM
Area Classification	Zone/Div 1/2 available
Coolant	8 SCFM @ 90 PSIG typical (other cooling media such as propylene possible) CUSTOM DESIGNS AVAILABLE TO SUIT MANY APPLICATIONS

Technical specification are subject to change without notice.

MODEL AND SUFFIX CODES

YARS100 Matrix and Advance Reflux Sampler

Base Model	Suffix Codes	Description
YARS100		Advanced Reflux Sampler
Heat Exchanger Assembly	-SAA -REC	Self Acting Adjustable Remote Electronic Control
Process Connection	-21 -23 -31 -33	2" 150# ANSI RF Flange 2" 300# ANSI RF Flange 3" 150# ANSI RF Flange 3" 300# ANSI RF Flange
----	-N	Always -N
Options	/12 /15 /S2	Thermo Over Temp Valve 120F Thermo Over Temp Valve 150F Liquid Cooling Media

YOKOGAWA HEADQUARTERS
9-32, Nakacho 2-chome,
Musashinoshi
Tokyo 180
Japan
Tel. (81)-422-52-5535
Fax (81)-422-55-1202
E-mail: webinfo@mls.yokogawa.co.jp
www.yokogawa.com.jp

YOKOGAWA EUROPE B.V.
Euroweg 2
3825 HD Amersfoort
The Netherlands
Tel. +31 (0)88-4641000
Fax +31 (0)88-4641111
E-mail: info@nl.yokogawa.com
www.yokogawa.com/eu

YOKOGAWA CORPORATION OF AMERICA
2 Dart Road
Newnan GA 30265
United States
Tel. (1)-770-253-7000
Fax (1)-770-251-2088
E-mail: info@yca.com
www.yokogawa.com/us

YOKOGAWA ELECTRIC ASIA Pte. Ltd.
5 Bedok South Road
Singapore 469270
Singapore
Tel. (65)-241-9933
Fax (65)-241-2606
E-mail: webinfo@yas.com.sg
www.yokogawa.com.sg

Yokogawa has an extensive sales and distribution network. Please refer to the website (www.yokogawa.com/an/index.htm) to contact your nearest representative.



YOKOGAWA ◆

GS11A00V01-01E-A
Subject to change without notice
Copyright © 2008

Printed in The USA, 03-1208 (A) I